


Majortel Systems: Full Content Explanation

Alarm Summary Indicator

Major Class – presents a red LED on the front panel.
Minor Class – presents a yellow LED on the front panel.

Alarm Relay Mapping

Operators use this option to establish mapping of specific alarms onto one of two dry-contact relays. In addition to mapping an alarm to a relay, the alarm level can be classified as either major, minor or ignore.



Alarm Relay Position* – Normal Status

All Majortel Systems ship with relay positioning set to **Normal-Close** operation. Relay status position can be programmed using the front panel buttons on the MTS-Com. Dry-contacts are designed to make or break the alarm circuit supplied by the operator installation.

Alarm Tone On/Off

Operator programmable option for the audible alarm tone. Default setting is OFF. Active alarm audible tones will time out after 75 seconds. The active alarm will remain on the active status page.

Alarm Active Status

View the active alarms for the system being monitored.

Alarm History File Clearing

The alarm history table will store 200 events. Each event receives a time stamp. Round file operation will overwrite the oldest table entry.

Charge Rate and Current Limit


Reference Tech App Note AN-010-14N for a detailed description of charging parameters.

Force Equalize Charge*

Define interval in days.
Waiting period, in days, between pre-programmed charge routines.

Define time limit*


The time in minutes before an equalize charge will cease and the system returns to float voltage operation.



Battery Size

Operator programmed battery size based on the installation. Numerical value in Amp-Hours. This value is important to the calculation of the current limit function during recharge.

Majortel Systems: Full Content Explanation



Low Voltage Battery Disconnect trigger

The voltage set in this parameter is used by the controller to open the internal contactor in the battery circuit. The contact will close the circuit after a system bus voltage is normal. Typical disconnect voltage is calculated by using 1.75 volts per cell for the battery installation. By example, in a telecom network configuration, 24 cells X 1.75 volt equals a 42V trigger setting to open. (MTS-130V excluded)

Ambient Temperature Monitoring

A temperature probe is shipped with each Majortel dc power system. Once the probe is connected, the system will register the ambient temperature measured in the location and display this information. The probe is equipped with a 3 meter cable which allows positioning near the battery. The registered temperature is also used by the controller for the temperature compensation calculations and voltage adjustment.

Temperature Compensation Operation

Define center temperature:

Default center temperature setting is 25° C.

Define compensation coefficient

User defined parameter used in the calculation to modify charge voltage in relationship to the change of temperature as measured. This setting will affect system overall voltage.

User and Supervisor Passwords*


Two password levels in the Majortel controller. The user level password is used for basic monitoring. The supervisor level password includes system settings and password control options.

Firmware Revision

This is a *read only* field for viewing firmware installed in the controller being monitored.

Network Controls

IP Address / Network Mask / Gateway / Email



MTS-Com web screen refresh is built for 90 second cycles. The long refresh window allows administrator access time to make and save changes.

* Local Access: Management on-site with administrator privileges.

** Sample screens above may change based on system type and firmware load.