MAJORSINE Inverter Manual / M101.8

6-3 Alarms

- > Inverter Alarm Classifications & Conditions
 - > Fault Alarm Indicator includes:

Bypass AC Input High or Low Voltage	Bypass AC Input Frequency Deviation
Fan Fail	Inverter Internal Failure
Output Load Sensing "short" condition	High Temperature

> DC Abnormal Indicator includes:

Input Low Voltage	Input High Voltage

DCV Input	24 V	48 V	125 V
DC Low Voltage Trigger	21	42	101
DC Low Voltage Recovery	22	44	103
DC High Voltage Trigger	29	59	149
DC High Voltage Recovery	28.5	58.5	148.5

